

8. Using the continuity checker, make sure that pin 31 of OSROM LOWER (U5) is not connected to the via that the trace goes to (make sure the cut is all the way through the trace).
9. **TS-10:** Go to Section D.  
TS-12: Go to Section F.

## H. Disk Storage

### Formatting a TS Disk

- Insert a disk into the disk drive (double density or high density)
- Press Storage.
- Select DISK.
- Select \*FORMAT\*. The display shows DISK NAME=1SD-000.
- Use the **Up/Down Arrow** buttons to change the character, then use the soft buttons below LEFT and RIGHT to move the cursor (underline) to the next character.
- Select \*FORMAT\* to proceed (or \*EXIT\* to leave this page with no harm done). The display shows FORMAT DISK ALL DISK FILES WILL BE ERASED. Press \*YES\* to proceed, or \*NO\* to abort the command.
- While the unit is formatting the disk the display reads FORMATTING DISK PLEASE WAIT... The formatting process takes about 80 seconds.
- When the formatting is done, the display reads DISK COMMAND COMPLETED, and then you are returned to the Storage page.

### Saving TS Data to a Disk

You will be saving four (4) different files: 60-SEQ/SONGS with 120 programs; 120-PRESETS; SYSTEM-SETUP; and SAMPLE-BANKS.

- Insert a formatted disk into the disk drive.
- Press **Storage**.
- Select DISK.
- Select SAVE.
- Move the **Data Entry Slider** (or use the **Up/Down Arrow** buttons) until the display shows FILE TYPE=6Q-SEQ/SQNGS.
- Select \*YES\*. The display shows SAVE NO PROGRAMS IN SEQ FILE.
- Move the **Data Entry Slider** to change NO to 120.
- Select \*YES\*. The display shows SAVE FILE NAME=60-SEQ/SONGS.
- Use the **Up/Down Arrow** buttons to change the character, then use the soft buttons below LEFT and RIGHT to move the cursor (underline) to the next character.
- Select \*YES\*.
- After the unit is done saving, it returns to the SAVE FILE page.
- Move the **Data Entry Slider** (or use the **Up/Down Arrow** buttons) until the display shows TYPE= 120-PRESETS.
- Select \*YES\*. The display shows SAVE FILE NAME=I20-PST-FILE.
- Use the **Up/Down Arrow** buttons to change the character, then use the soft buttons below LEFT and RIGHT to move the cursor (underline) to the next character.
- Select \*YES\*.
- After the unit is done saving, it returns to the SAVE FILE page.
- Move the **Data Entry Slider** (or use the **Up/Down Arrow** buttons) until the display shows TYPE=SYSTEM-SETUP.
- Select \*YES\*. The display shows SAVE FILE NAME=CONFIG-FILE.